

Sponsor: M. Rankine Forrester Intoximeters, Inc. 2081 Craig Rd. St Louis., MO 63146

## Viral Filtration Efficiency (VFE) at an Increased Challenge Level Final Report

Test Article: 23-00095-01
Purchase Order: PO-0008117
Study Number: 1342825-S01

Study Received Date: 17 Sep 2020

Testing Facility: Nelson Laboratories, LLC 6280 S. Redwood Rd.

Salt Lake City, UT 84123 U.S.A.

Test Procedure(s): Standard Test Protocol (STP) Number: STP0010 Rev 15

Deviation(s): None

**Summary:** This test procedure was performed to evaluate the VFE of test articles at an increased challenge level. A suspension of  $\Phi$ X174 bacteriophage was delivered to the test article at a challenge level of greater than  $10^6$  plaque-forming units (PFU) to determine the filtration efficiency. The challenge was aerosolized using a nebulizer and delivered to the test article at a fixed air pressure and flow rate of 30 liters per minute (LPM). The aerosol droplets were generated in a glass aerosol chamber and drawn through the test article into all glass impingers (AGIs) for collection. The challenge was delivered for a one minute interval and sampling through the AGIs was conducted for two minutes to clear the aerosol chamber. The mean particle size (MPS) control was performed at a flow rate of 28.3 LPM using a six-stage, viable particle, Andersen sampler for collection. The VFE at an Increased Challenge Level test procedure was adapted from ASTM F2101.

This test procedure was modified from Nelson Laboratories, LLC (NL), standard VFE test procedure in order to employ a more severe challenge than would be experienced in normal use. All test method acceptance criteria were met. Testing was performed in compliance with US FDA good manufacturing practice (GMP) regulations 21 CFR Parts 210, 211 and 820.

Challenge Flow Rate: 30 LPM

Area Tested: Entire Test Article Side Tested: Larger Orifice Challenge Level: 8.6 x 10<sup>6</sup> PFU

MPS: ~3.2 μm

Test Monitor Results: Acceptable

James Luskin electronically approved

Study Director James Luskin

22 Oct 2020 18:10 (+00:00)

Study Completion Date and Time

801-290-7500

nelsonlabs.com

sales@nelsonlabs.com

FRT0010-0001 Rev 15 Page 1 of 2



## Results:

| Test Article Number | Total PFU Recovered   | Filtration Efficiency (%) |
|---------------------|-----------------------|---------------------------|
| 1                   | 6.1 x 10 <sup>3</sup> | 99.930                    |
| 2                   | 5.9 x 10 <sup>3</sup> | 99.931                    |
| 3                   | 4.7 x 10 <sup>3</sup> | 99.946                    |

The filtration efficiency percentages were calculated using the following equation:

tjl